

INFANT RADIANT WARMER HKN 90

Imported servo control panel,

Made as China

Warmer HKN 90

Baby temperature indicator display the baby temperature.

Heater power indicator

Indicate the heater output proportion .

Alarm classification indicator .

If the alarm active,the relative light is flashing .

Time Indicator

**Under the APGAR timerstate,the timeunit is second .
while under the timer state , the unit is minute.**

Time key

Press to enter into the time state.

APGAR Time key

Press o enter into the state of APGAR

**The power switch of controller turn on or turn off the
controller**

Baby mode Light

This light is on when it is in the

Set temperature indicator

**Indicates the set temperature value in baby mode while it indicates --- in the pre-warm mode and the manual mode ,
it indicates the alarm code when alarm active**



